KBL

Tower space 2000



TANNING DEVICE

ASSEMBLY INSTRUCTIONS & MENU SETTINGS

Copyright and Trademark

© Copyright 2018 KBL GmbH

This documentation only covers products manufactured by KBL GmbH. It must not be duplicated, photocopied, translated or stored without prior special consent by KBL GmbH. Duplication on electronic media or in a machine readable form, either in whole or in part, is also prohibited.

KBL is a registered trademark of KBL GmbH.

DISCLAIMER

All information given in this document correspond to the status quo at the date of publication but may be subject to changes. Therefore, we do not accept any liability for, nor do we guarantee the accuracy and/or completeness of the information.

EXPORT

Technical equipment and versions of the devices are in accordance with the legal prescriptions of the respective country of destination. Export to the European Union of the KBL products, listed in this guide, or operation of the systems in these countries, are not permitted. KBL does not accept any manufacturers liability in case this direction is not adhered to. It is expressly pointed out that any violation of the export/operation prohibition will involve substantial risks of liability for the exporter and/or operator.

ORIGINAL ASSEMBLY INSTRUCTIONS
Version: MA_space2000_US_J
Date: June 2018
Item no: 0100036002
Tanning device name [tech.]: T3/50 - 180 u

MANUFACTURER
KBL GmbH
Ringstraße 24-26 · 56307 Dernbach · Germany

DISTRIBUTED BY (CONTACT)
Specified in operating instructions

Contents

1. General information 5
1.1 About these instructions 5
1.2 Safety signs 5
1.3 Signal words 5
1.4 Transport 6

2. Safety notes 7
2.1 General safety notes 7

3. Installation site and dimensions 8
3.1 Dimensions 8
3.2 Distances 9

4. Assembly 10
4.1 Tools and aids 10
4.2 Option: Alteration exhaust air outlet 10
4.3 Option: Alteration for central exhaust air ... 10
4.4 Assembling the tanning device 10

5. Connections & Initial operation 26
5.1 Class I ME equipment 26
5.2 Overview supply connections 26
5.3 Connecting the mains voltage 26
5.4 Connecting an external audio source 27
5.5 Level adjustment studio music 27
5.6 Operation using different audio sources 27
5.7 Bluetooth connection 28
5.8 Connecting the channel selection 29
5.9 Connecting the external timer 29
5.10 aquaCool-box connections 30
5.11 Connections aquaCool box /tower 30
5.12 Initial operation 30

6. Service menu 31
6.1 Layout of the interior control panel numbers 31
6.2 Invoking the service menu 31
6.3 Service menu - Basics 32
6.4 Service menu - Overview 34
6.5 Service codes 35
6.6 Service menu - options 35

1. General information

1.1 About these instructions

This manual is intended for use by

- qualified, trained and authorized service technicians.

Any person handling, mounting or servicing this tanning device must have read and understood these instruction.

Keep this manual ready to hand at all times.

1.2 Safety signs



This symbol indicates that general hazards exist for the human health.



This symbol indicates that due to electrical tensions hazards exist to the human health.



This symbol indicates that due to falling loads hazards exist to the human health.



This symbol indicates the danger of pinching.
When assembling heavy components, you can pinch your fingers or hands.



This symbol indicates the danger of burns from hot lamps and housing parts.
If the tanning device was operated before being opened, lamps and housing parts may be hot.




This symbol indicates that damages may occur at the tanning device, at the material or at the environment.



Danger due to leakages.

The tanning device can be damaged by leaking connections.

- Slide the plastic tube **up to the stop** into the quick connector socket.



1.2.1 IMPORTANT INFORMATION



This symbol does not identify safety notices, but states information for a better understanding.

1.3 Signal words

DANGER

- Death or serious injury is imminent.

WARNING

- Death or serious injury is possible.

CAUTION

- Moderate or minor injury is possible.

1.4 Transport



WARNING

Overturning load

Danger of being crushed by heavy parts of the equipment.

- Keep the safety distance to the transport machine.
- Do not walk under the load.
- Wear safety shoes.

1.4.1 TRANSPORT BY FORKLIFT TRUCK



During transport the tanning device may be damaged when using forklift forks that are too short.

- Use only sufficiently long forks.

The box with the tanning device components is mounted on a pallet.

- Insert the forks carefully into the openings of the pallet.
- Lift the load by a few centimeters.
- Transport the load carefully to the place of installation.

1.4.2 OTHER MODES OF TRANSPORT

If a forklift truck cannot be used for transport, the box must be unpacked and the parts inside must be transported individually to the place of installation, e.g. using a dolly. Depending on the weight of the components, lifting them might require several people.

2. Safety notes

2.1 General safety notes

- Follow all instructions given in this manual and all other documents enclosed with the tanning device. In addition, observe all relevant statutory provisions and regulations, also those applicable in the country of operation.
- The tanning device must only be installed and assembled by qualified, trained and authorized service technician.
- Arbitrary modifications or conversions of the tanning device are not permissible.
- Observe all danger signs and safety notices attached to the tanning device.
- Safety notices must not be removed, and safety equipment must not be disabled or removed.
- The tanning device must only be operated when in perfect working condition.
- Never operate the tanning device with the outer covers or acrylic panes removed.
- This tanning device must be operated with an external timer that is listed in compliance with UL 917.
- Before carrying out any work, the tanning device must be disconnected from the mains voltage.



DANGER

Live parts

Danger of life or fatal injury due to electric shock when touching live parts.

- Switch neutral
- Secure against reconnection
- Check for neutrality
- Ground and short-circuit
- Cover or shield any adjacent live parts or components



CAUTION

Hot surfaces

Danger of burns from hot lamps and housing parts. If the tanning device was operated before being opened, lamps and housing parts may be hot.


- Wait until the tanning device has cooled down.


3. Installation site and dimensions


In dry rooms (booths) with sufficient airing.

- Even floor with sufficient load capacity
- Relative humidity: ≤ 70 %
- Room temperature ≤ 30 ^{0}C (86 ^{0}F)
- Minimal room height 2270 mm (≈89,37 inches)
- Only on a non-combustible basement


3.1 Dimensions









3.2 Distances








4. Assembly

4.1 Tools and aids

- Assembly of the tanning device has to be done with two persons.
- Combination spanner: SW 13, 17
- Suction cup
- Phillips screwdriver
- Set of Allen keys
- Set of socket spanners
- Potentially ladder


4.2 Option: Alteration exhaust air outlet

Factory-made, the exhaust air outlet is on the upper side. If the exhaust air is to be let out on the lower side, the exhaust air grid has to be exchanged with the exhaust air cover and the fan accordingly.




4.3 Option: Alteration for central exhaust air

If the tanning device has to be connected to the central exhaust air, the exhaust air grid has to be exchanged with the exhaust air socket.




4.4 Assembling the tanning device





The line of sight used in the text is from the door side to the back side.

- Lay down the baseplate and the associated pad for its entrance area. The baseplate has pits for the feet of the back plane and side plates.





- Place the back plane into the corresponding pits. Fix one angle at the right and one angle at the left side of the back plane. Fix the box with the fan. Observe the minimum and maximum height when adjusting.







- Place the side plates into the pids and adjust side plates with the back plane (even and flush). Fix the side plates according to the picture. **Adjust with level.**








- On both sides, lead the cable harness from the back plane through the sickel shaped metal to the side plate. Fix it in the lace.




- Push the door between the upper and lower crescent of the left side part. The door is attached with the bushing located on the wire harness ① ②. Here, ensure that the bushing is installed with flat side positioned as in the illustration and attached with 2 M5 x 6 mm slotted screws ②. Then, place the wire harness in the gap ③. With the included bushing, attach the door to the lower crescent ④ ⑤. Here, ensure once again that the flat side is positioned as in the photo ⑤. Attach this bushing with 2 M5 x 6 mm slotted screws as well.




















- Measure the distance between top edge of the side plate and top edge of the door. The space should be max. 10 mm at the left and the right side.







- If the height difference is outside the range, the alignment of the lateral parts towards each other must be checked (page 9). If the limit is not observed in spite of a correct alignment of the parts, the alignment is done by adapting the front feet of the tanning device instead. Please note that their minimum height is 48 mm, the maximum height is 60 mm.



- Place the ceiling part on top of the tanning device and fix it according to the picture. When tightening the screws one person lifts the door up slightly while the second person fastens the top of the tanning device. Don‘t jam the cable harnesses.




- At the right side, pull the following cables and hoses out of the ceiling part: five hoses (2x aroma, 2x aquaCool, 1x air for aquaCool), Harness with molex connector (music), one cable with jack plug (line in), one cable with RJ22 plug (display), Harness with connectors X7 and X4/X2.




- Connect: 2x aroma






- 2x aquaCool liquid and 1x aquaCool air (BLUE)






- 1x display (RJ22) and 1x line-in (jack plug)






- 1x music (molex connector).





- Connect X.2/X.4 with X.4. X.7 -> only for devices with decorative lighting in the ceiling part.





- Hook in the ballast boards at the left side plate. The boards with more ballasts (as with model with 52 tubes) are placed at the left side.



- Connect the cables in the left side plate.



- Hook in the side and door coverings.












- Fix the door handle.



- Fix the inside handles according to the picture.



- Attach the door spring ① between the two spring seats ② ③.




5. Connections & Initial operation

5.1 Class I ME equipment

WARNING

Risk of electric shock
To avoid the risk of electric shock, this equipment must only be connected to a supply mains with protective earth.

5.2 Overview supply connections



1	Mains voltage aquaCool box
2	Audio connection / channel selection
3	aquaCool - air (blue)
4	Aroma
5	aquaCool - liquid
6	Connection of external timer (coin-box system)
7	Power supply
8	Data cable Tower/aquaCool-Box

5.3 Connecting the mains voltage

DANGER

Live parts
Danger of life or fatal injury due to electric shock when touching live parts.

- Switch neutral
- Secure against reconnection
- Check for neutrality
- Ground and short-circuit
- Cover or shield any adjacent live parts or components

Both the power supply and the related connection work must comply with national standards and local regulations. The connection work and replacement of the power supply cord must only be performed by qualified, trained and authorized service technicians. The connection to the 3 x 220 V mains must be protected by maximum over current protection. For Canada a Class-A ground fault circuit interrupter (GFCI) has to be used. Further information can be found in chapter “Technical data”.


CONNECTION REQUIREMENTS

The electrical installation must be equipped with a freely accessible all-pole disconnecting device in accordance with the overvoltage category III (Master switch with clearly marked on/off settings e.g. “O” and “I” or additional indicator light), fitted externally on the site side. This means that for full separation each pole must have a contact gap according to the conditions of the overvoltage category III.


The device shall be capable of being locked in the off-position and shall comply with IEC 60447. A supply main switch must not be incorporated in the power supply cord.

A Class-A ground fault circuit interrupter (GFCI) has to be used for Canada. Should the operation of the

tanning device cause any interference in the power supply network, e.g. with ripple-control systems (TRA), consult your power supply company to have corresponding blocking elements (audio frequency suppressors) installed.




The tanning device is by default set up to operate on 3 phases but it can be changed over to 2-phase operation. The wiring for 3-phase operation is shown below:




The wiring for 2-phase operation is shown below.

- Re-wire the 3 cables according to the diagram.
- Make sure that you use the right cable for the power supply.




5.4 Connecting an external audio source

The cinch marked in the illustration is connected to the external audio source where the line-out of the sound player or the headphone/loudspeaker jack are available for connection.



5.5 Level adjustment studio music

The voice / audio system components are installed in the back part of the tanning device. The potentiometer which serves to adjust the external audio signal level is accessible through a maintenance hatch on the left hand side of the tanning device. To avoid overdrive, select the level adjustment accordingly. The level setting depends on the strength of the external signal and should be carried out by a qualified, trained and authorized service technician.



5.6 Operation using different audio sources

The tanning device can be operated using the following audio sources:

- An internal audio source
- Various external audio sources
- All available audio sources

The audio source can be changed via the control panel.

INTERNAL MP3 PLAYER

When using the internal MP3 player, you can either play the music tracks that are originally supplied on the SD card, or you can record your own tracks to the SD card.

EXTERNAL AUDIO SOURCES - LINE IN

As an external audio source, you can connect devices ranging from the standard-line level to low loudspeaker levels.

These sources comprise:

- Studio music
- External players such as MP3 players, mobile phones (cell phones), I-pods, etc.


EXTERNAL 100 V AUDIO SIGNAL ON STUDIO CHANNEL (OPTIONAL FEATURE)

If you decide for a connection to a 100 V audio system, you will need a transformer (KBL no.: 9100 0170 00) for the transmission of the audio signal.

This connection must be made by qualified, trained and authorized service technicians.

EXTERNAL PLAYERS

A line connection has been integrated into in the head area near the interior control Panel so that the user can connect his or her own player such as an MP3 player, an iPod, etc. Use a standard 3.5mm jack cable (included if the music option has been ordered). Connect the jack plug to the earphone jack of your player. Then select ”MP3 ext.” as the audio source from the inerior control panel of the tanning device before you start playing your own tracks from the player. The tracks can only be selected via the user’s own player. The volume can be controlled via the control panel of the tanning device and also via the corresponding operating elements provided by the user’s player.



5.7 Bluetooth connection

To connect an external player (smartphone etc.) wirelessly to the tanning device an optional Bluetooth interface is available.


CONNECT EXTERNAL PLAYER

A bluetooth connection can be established in standby and during tanning mode.

ⓘ	Make sure that you are within the reception area (about 2 meters). Make sure that your player is configured to search for other bluetooth devices. Should this not be the case, enable bluetooth manually. To do so, please read the instructions for your player.

- Depending on your settings the search will be performed automatically or manually. All available bluetooth devices within reach will be listed after a short time.
- Among the available tanning devices choose “KBL Sound”. In the service menu, a trailing number (01, 02, 03, ...) can be added to tanning device name.
- If necessary confirm the shown code and connect again. Not every smart phone asks for a code.

Example - Samsung Galaxy




Example - Apple iPhone



- A two-time beep indicates that your player is connected to the tanning device.

Example - Samsung Galaxy



Example - Apple iPhone



- Set your player to a **medium volume level** and start the music.
- Adjust the volume level on your player.
- During the tanning session, the volume control has to be done at the tanning device.

DISCONNECT EXTERNAL PLAYER

An existing connection is disconnected automatically after tanning.

The connection is automatically disconnected if the tanning session is not started within 6 minutes.

COMPATIBILITY OF BLUETOOTH DEVICES

KBL GmbH attaches great importance to hardware compatibility. Due to the large number of manufacturers, KBL can not guarantee a 100 % compatibility. In rare cases, it may happen that a bluetooth connection can not be established.

CORRECTIVE ACTION


Each bluetooth device offers a list of paired devices. Delete the older entries in this list which have a profile that overlaps with the ones for which you want to pair your player.

Start the bluetooth device detection again.


5.8 Connecting the channel selection

The following diagrams show the wiring of the channel selection on the audio equipment's side, for pulse coding as well as for BCD coding.

Wiring on the audio system of the studio



Wiring on the audio system of the studio




CHANNEL	BCD 0	BCD 1
1	0	0
2	1	0
3	0	1
4	1	1


5.9 Connecting the external timer

CONNECTING VIA AMP PLUG (DEFAULT)


Connect the external timer (e.g. coin box, studio control) according to the instructions supplied with the timer. The connection is made via the socket for an AMP plug on the back side of the device. The following diagram shows the wiring of the timer connection.



T-MAX BOX




T-MAX CONNECTOR PANEL




- The exposure times stated in the exposure schedule must be entered at the External Studio Timer.
- Information on how to enter the exposure time can be found in the operating instructions of your Studio Timer.

5.10 aquaCool-box connections



1	aquaCool - liquid
2	aquaCool - air (blue)
3	Aroma
4	Mains voltage aquaCool box
5	Data cable Tower/aquaCool-Box

5.11 Connections aquaCool box /tower



5.12 Initial operation

- Turn on the supply voltage.
- Start the aquaCool initialisation before tanning for the first time. Service menu “Aqua / aquaCool Start Initialisation“
- Test all functions in a trial run.
- Remove all protective films.
- Clean the tanning device.


6. Service menu

While the tanning device is in standby mode, you can switch the decorative lighting of the tanning device on and off and trigger an aquaCool spraying test (1 spraying cycle).

When the tanning device is in service mode, you can make the presettings for operation in tanning mode, and you can have values concerning the operation of the tanning device displayed.

6.1 Layout of the interior control panel numbers

The buttons of the interior control panel are allocated double functions. In addition to the standard operating elements, they stand for numbers that, in standby mode, provide access to standby and service functions. Simply enter the corresponding sequence of numbers on the interior control panel.




6.2 Invoking the service menu

CALL SERVICE MENU - START WINDOW



SERVICE MENU - START WINDOW



In standby mode, the service level is accessed by entering the factory CODE 1 „00000“, the supplied CODE 2 or individually defined CODES.

- No incoming signal from the coin-box system.

NOTE


Do not let too much time pass between the individual keystrokes when entering a sequence of numbers!

6.3 Service menu - Basics

SERVICE MENU - STANDARD OPERATING ELEMENTS

After having entered the service CODE, the service menu is at your disposal. Navigation is made via the following buttons (see also chapter: Layout of the interior control panel numbers):


- Use buttons 4 (UP) and 9 (DOWN) to browse through the individual menu items and functions.
- Press the START/ENTER button to go to the corresponding submenu.
- Button 2 and 7 are used to switch functions on and off and to modify values.
- Press 3 (STORE) to save all modifications made in all menu items.
- Press 8 (EXIT) to go back to the previous menu level or to exit the service menu.



SERVICE MENU - BASIC OPERATION


The service menu is divided into the main menu and subordinate groups of functions.

If you choose a menu item, e.g. “AUDIO”, you will get access to all functions related to this item.




- Select the desired function group from the main menu by pressing the 4 (UP) or the 9 (DOWN) button. The currently selected group is highlighted.

- Press the START/ENTER button to access the desired group menu.





- The currently active function (circle) is displayed in the centre line on the left-hand side. You can invoke further functions of this group by pressing 4 (UP) or 9 (DOWN).




CHANGE SETTINGS

- Depending on the respective function, you can change values, select options and switch functions on or off. To do so, use the buttons 2 (+) and 7 (-).









STORE & EXIT

- Save your settings by pressing the button 3 (STORE). If you fail to do so, the system will not take over the changes you made. -> See also chapter “Service Menu - Timeout”.
- By pressing the STORE button, you save all changes you have made in all menu items.



- By pressing 8 (EXIT), you go back to the previous menu level, or you exit the service menu.



SERVICE MENU - TIMEOUT

After performing your last operating action, you have 2 minutes left to save the changes you have made. Then, a prompt appears and all changes are automatically discarded after an additional 20 seconds.

SERVICE MENU - AUDIBLE SIGNALS

For user convenience, operation and storage processes are acoustically acknowledged in different ways:

Operation process	->	short sound
Storage process	->	long sound

KBL-7

6.4 Service menu - Overview

ENVIRONMENT

① Language
② Contrast
③ TIME AND DATE
④ TIMER DECORATIVE LIGHTING
⑤ Maximum tanning time

HOUR METERS

⑥ Operating hours overall
⑦ Operating hours UV tubes
⑧ Operating hours collagen tubes
⑨ Number of sunbath

PRESELECT

⑩ UV-Typ
⑪ Audio
⑫ Voice (megaVoice)
⑬ Aircon (aircondition)
⑭ Aroma
⑮ Aqua (aquaCool)

AUDIO

⑯ MP3 internal
⑰ megaVoice
⑱ megaVoice language
⑲ Studio (Line-in)
⑳ usb MP3
㉑ MP3 external (Line in)
㉒ Studio channel selection
㉓ Number of studio channels
㉔ Musik nonstop
㉕ Nonstop music source
㉖ Default volume tanning
㉗ Default volume standby
㉘ Maximum adjustable volume
㉙ megaVoice volume adaption
㉚ Dynamic volume adaption
㉛ Treble MP3 - USB
㉜ High bass MP3 - USB
㉝ Low bass MP3 - USB
㉞ Volume adaption Studio Line-In
㉟ Treble Studio Line-In
㊱ High bass Studio Line-In
㊲ Low bass Studio Line-In

AQUA

㊳ aquaCool
㊴ aquaCool spray time
㊵ Cycle time
㊶ aquaCool start test cycle
㊷ aquaCool endurance test
㊸ aquaCool start initializatio

AROMA

㊹ Aroma
㊺ Aroma status reset
㊻ Cycle time
㊼ Aroma cabin automatic
㊽ Aroma cycles per hour
㊾ TIMER AROMA
㊿ Aroma start test cycle

AIR CONDITIONING

(51) Air condition
(52) Start level body fan

RGB

(53) RGB mode

(54) **EASYCARE**

(55) **UV-LEVEL**

SERVICE

(56) Load factory defaults
SERVICE-CODE
(57) Service Code Level 1
(58) Service Code Level 2
BLUETOOTH
(59) Name
(60) Powerlevel
(61) FIRMWARE-TYP
(62) FIRMWARE-VERSIONS
(63) SOFTWARE UPLOAD
(64) RGB-Setup
SERVICE MODE
(65) Service mode without tanning
(66) Service mode with tanning
(67) SOLARIUM IDENTIFICATION
(68) SOLARIUM X-CODE
(69) Reboot

(70) **EVENT LOG**

6.5 Service codes

SERVICE-CODE LEVEL 1

Access to the service menu start window is protected by CODE 1. When delivered, this CODE is **00000**. Optionally, the factory-set protection can be **replaced** by an individual CODE in the service menu, item

>SERVICE/SERVICE-CODE/Service Code Level 1<

SERVICE-CODE LEVEL 2

Some menu items are protected by CODE 2. Each tanning device has its own CODE 2.

You will receive your CODE 2 (Service Code Level 2) with the tanning device documentation.


megaSun
Important document - Keep in records
Wichtiges Dokument – Bitte aufbewahren
Service Code Level 2
Company / Firma:
Installation site / Aufstellort:
Device / Gerät:
Factory setting / Werkseinstellung
Individual setting / Individuelle Einstellung

Optionally, the factory-set CODE 2 can be **supplemented** by an individual CODE 2 in the service menu, item

>SERVICE/SERVICE-CODE/Service Code Level 2<

Access to the service menu start window can be done directly with the CODE 2. In this case all CODE 2 protected menu items are immediately activated.

- The factory-set CODE 2 remains valid even if an individual CODE 2 is set.
- Individual CODES are not reset by loading the factory settings.
- The one-time input of CODE 2 immediately activates all protected menu items.


In the following chapter, you will recognize CODE 2 protected menu items by the service menu.

6.6 Service menu - options

In order to avoid operating errors, read through the basics at the beginning of the “Service Menu” section.

- Always remember to save your settings by pressing STORE.
- All menu items that comprise further submenus are displayed in CAPITAL LETTERS.

①




> German
> English

Sets the language of the menu.

Factory setting: German

②




> 00000...00030

Sets the contrast of the interior control panel display.

Factory setting: 00020


③



Entry of date and time. Invoke the submenu by pressing START (ENTER).



SUBMENU
TIME & DATE




The menu item „Timer decorative lighting“ offers you two switching cycles (A and B) for each day of the week.

NOTE - SWITCHING CYCLES


Using the setting „monday-sunday“, the switching cycle will be the same for each day of the week.

Week	Switching cycle A	Switching cycle B
Monday - Sunday	A-ON	B-ON
	A-OFF	B-OFF

Day	Switching cycles A	Switching cycles B
Monday	A-ON	B-ON
	A-OFF	B-OFF
Tuesday	A-ON	B-ON
	A-OFF	B-OFF
Wednesday	A-ON	B-ON
	A-OFF	B-OFF
Thursday	A-ON	B-ON
	A-OFF	B-OFF
Friday	A-ON	B-ON
	A-OFF	B-OFF
Saturday	A-ON	B-ON
	A-OFF	B-OFF
Sunday	A-ON	B-ON
	A-OFF	B-OFF



4



Entering switching times for the decorative lighting.
The submenu is invoked by pressing START (ENTER).




SUBMENU
TIMER DECOLIGTH

SELECT WEEK OR DAY OF THE WEEK




> Monday - Sunday




ENTER SWITCHING TIME



> (Day) AON
> (Day) AOFF
> (Day) BON
> (Day) BOFF




SET SWITCHING CYCLES



> 00:00 - 23:59

+/- Set the time



Select input fields

- Save settings by pressing STORE!


5

code 2




Not available in this system.

6



Displays the total operating hours.

7




> 0183h

Displays the total operating hours of the tubes and includes a reset function and set function to set the value in steps of five via the +/- buttons.

- Save settings by pressing STORE!


8



> 0156h

Not available in this system.


⑨



Indicates the number of tanning sessions (sunbaths) and includes a reset function.


Under the menu item "PRESELECTION" you can make the initial settings for the "preSelection" functions. The functions must be available and activated in this service menu ⑯/⑰/⑲/㊳/㊹/㊿.

⑩



Not available in this system.

⑪




> Studio Line-In
> MP3-internal
> MP3-external

Determines the start setting of the audio source.

Factory setting: MP3-internal

⑫




> on
> off

Specifies the start setting of the voice-guidance system.


Factory setting: on

⑬



Not available in this system.

⑭




> on
> off

Defines the start setting of Aroma.

Factory setting: on

⑮




> on
> off

Specifies the start setting of aquaCool.

Factory setting: on

⑯




> on
> off

Activates and deactivates the internal MP3 player.

Factory setting: off

⑰



> on
> off

Activates and deactivates the voice-guidance system (megaVoice).

Factory setting: on

18



> English
> German
> ...

Fixes the language setting of the megaVoice system. The following languages are fully supported: GB,RU,DE,FR,IT,PL,CZ,NL,HU,BG,HR,RO,RS,SK The following languages are supported in part: DK,EE,LT,NO,ES,SE,TR (without easyCare)

Factory setting: Depending on the operator country

19




> on
> off

Activates and deactivates the Studio (line-in) audio signal.


Factory setting: on

20



Not available in this system.

21




> on
> off

Activates and deactivates the line-in connection (bench part, right-hand side of the head end) for units from standard-line level to low loudspeaker levels (MP3 player, iPod, etc.).

Factory setting: on

22



> bcd
> puls code
> off

Allows for the change-over between pulse-code and BCD-code mode with the Studio music signal pending and deactivates the external-channel selection.

Factory setting: BCD

23




> 2
> 4

If BCD has been preselected, the number of channels available in the studio is specified here.

Factory setting: 4

24




> on
> off

If this function is active, music is played nonstop, i.e. also out of tanning sessions.

Factory setting: off

25



> MP3-internal
> Studio Line-In

Allows for choosing the permanent audio source for the “Music nonstop” function“.

Factory setting: MP3-internal

26




> 0 .. . 9

Sets the volume for the tanning mode.

Factory setting: 6

27



> 0 .. . 9

Sets the volume for the standby mode.

Factory setting: 3

28



> 5 .. . 9

Presetting the maximum adjustable sound level, limits the maximum adjustable sound level in the operating and standby mode.

Factory setting: 9

29




> -09 .. . +09 dB

Here you can adapt the volume of megaVoice.

Factory setting: -07 dB

30




> on
> off

Dynamic volume adaption on-/off.

Factory setting: on

31




> -14 .. . +14 dB

Sets the treble for MP3 - USB operation.

Factory setting: +14 dB

32




> -14 .. . +14 dB

Sets the high-bass for MP3 - USB operation.

Factory setting: +08 dB

33




> -14 .. . +14 dB

Sets the low-bass for MP3 - USB operation.

Factory setting: +08 dB

34




> -29 .. . +29 dB

Here you can adapt the volume of studio line-in signal.

Factory setting: +00 dB

35




> -14 .. . +14 dB

Sets the treble for studio music operation.

Factory setting: +14 dB

36




> -14 .. . +14 dB

Sets the high-bass for studio music operation.

Factory setting: +08 dB

37




> -14 .. . +14 dB

Sets the low-bass for studio music operation.

Factory setting: +14 dB

38



> on
> off

Activates and deactivates the aquaCool function.

Factory setting: off

39




> 2 .. . 6 (sec)

Determines the duration of the aquaCool spraying time.

Factory setting: 6

40



> manuel
> 1 .. . 5 (min)

Defines the aquaCool and aroma cycle time (spraying time + spraying interval). If „manual“ is selected, by pressing the aquaCool- or Aroma plus button a spray cycle can be triggered.


Factory setting: manuel

41



Starts the aquaCool test (1 cycle).

42



> on
> off

Starts the aquaCool endurance test. After having selected and stored the “on” setting, you must leave the service menu and start a tanning session. Attention! aquaCool will continue to spray permanently during a whole tanning session.


Factory setting: off

43



Starts the aquaCool initialization process. A spraying cycle of 90 seconds is started to bleed the system before commissioning, after a repair operation or after a canister replacement.

44




> on
> off

Activates and deactivates the aroma function.


Factory setting: off

45



Reset -> after having exchanged the Aroma tin.

46




> manuel
> 1 .. . 5 (min)

Defines the aroma cycle time (spraying time + spraying interval). Only active in systems without aquaCool or disabled aquaCool. If „manual“ is selected, by pressing the aquaCool- or Aroma plus button a spray cycle can be triggered.

Factory setting: manuel

47




> Door contact
> Intervall
> off

The cabinet scent release can be set at intervals, controlled by a door contact switch, or completely deactivated.

Factory setting: off

48



> 1 .. . 6


For interval operation of the cabinet scent released, the number of scent releases per hour can be set here.

Factory setting: 3


The menu item „TIMER AROMA“ offers you a switching cycle for each day of the week.

NOTE - SWITCHING CYCLES

Using the setting „monday-sunday“, the switching cycle will be the same for each day of the week.



49




Entering switching times for the Aroma Timer.
The submenu is invoked by pressing START (ENTER).




SUBMENU
TIMER AROMA


SELECT WEEK OR DAY OF THE WEEK




> Monday - Sunday




ENTER SWITCHING TIME



> (Day) ON
> (Day) OFF




SET SWITCHING CYCLES



> 00:00 - 23:59

+/- Set the time



Select input fields (start / set)


- Save settings by pressing STORE!

50




Starts the Aroma test (1 cycle).

51



Not available in this system.

52




> 1 . . . 9

Specifies the “start speed” setting of the body fan at the beginning of the tanning.

Factory setting: 2


53



Not available in this system.


Note:
For tanning devices with LED technology, the desired RGB color mode is adjusted by the color-Motion controller.

54 code 2




Not available in this system.

55 code 2




These settings must only be made by trained service personnel!

56



Loads the factory (default) settings.

code 2




Submenu call
with START/ENTER.




SUBMENU
SERVICE CODE


Service Code Level 1 ⑰
Service Code Level 2 ⑱

57







Enter new service code 1 and repeat the entry.




Save settings by pressing STORE.

58






Enter new service code 2 and repeat the entry.



Save settings by pressing STORE.

code 2




Submenu BLUETOOTH.
Invoked by pressing
START (ENTER).



SUBMENU
BLUETOOTH

Name ⑲
Powerlevel ⑳

59



> 01 - 99

To fit your Studio environment (multiple units) different numbers can be added to the bluetooth device name (megaSun xx) of each tanning device.

Factory setting: 01

60



> 1 . . . 7

Sets the transmission power for bluetooth.
Factory setting: 4

61



Submenu call with START/ENTER. Displays the current firmware typ / variant.

62



Submenu call with START/ENTER. Displays the current firmware version of the system components.

Do not operate the system with different firmware versions!


- **All system components must be equipped with an identical firmware version.**

63




Submenu call with START/ENTER. Displays the first and the last Software-Upload.

64



Not available in this system.

code 2




Submenu SERVICE MODE.
Invoked by pressing START (ENTER).



SUBMENU
SERVICE MODE


Service mode without tanning ⑮
Service mode with tanning ⑯

65




Troubleshooting mode.
The service mode is switched on for 30 minutes. The mains voltage is connected. Error notifications are ignored, but tanning cannot be started.

66




Troubleshooting mode.
The service mode is switched on for 10 minutes. The mains voltage is connected. Error notifications are ignored, tanning can be started. After this period, there is a 3 minute restart lockout.

67



Show the characteristics of the tanning device:
- Configuration code
- Variant code
- Serial number


68 code 2



Branches to further configuration options.

These settings must only be made by trained service personnel!

69




Performs a restart of the electronics.

Attention

- **All unsaved changes will be discarded!**

70



Lists the latest 99 events (error codes & info-messages). Detailed information is available by pressing the Start button.

Example:

no.	time	date	code	tanning time
001	16:44	05.01.09	0011	03:23
002	15:22	05.01.09	0002	07:22
003	10:07	22.12.08	....	....
004	17:16	....		
005	....			
....				
099				

KBL

The Beauty & Health Company



Ringstraße 24-26
56307 Dernbach / Germany
fon: +49 (0) 26 89.94 26-0
fax: +49 (0) 26 89.94 26-66